

UNDERMOUNTING METHODS

Method A Full Undermount

Only the well of the bath remains visible, the entire bath deck is covered by the finishing material chosen. Baths with a completely flat deck can be undermounted using Method A.

Method B Partial Undermount

The bath deck is only partially covered by the finishing material chosen. Baths with a Flat deck of at least 3/4" on all 4 edges can be undermounted using Method B

